

COCKPIT PREPARATION

COCKPIT PREP..... COMPLETE (BOTH)
 GEAR PINS AND COVERS.....REMOVED
 SIGNS.....ON / AUTO
 ADIRS..... NAV
 FUEL QUANTITY..... KG.LB
 TO DATA..... SET
 BARO REF..... SET
 (BOTH)

BEFORE START

WINDOWS / DOORS..... CLOSED (BOTH)
 BEACON..... ON
 MOBILE PHONE..... OFF
 THRUST LEVERS..... IDLE
 PARKING BRAKE..... AS RQRD

AFTER START

ANTI ICE..... AS RQRD
 ECAM STATUS..... CHECKED
 PITCH TRIM % SET
 RUDDER TRIM..... ZERO

BEFORE TAKEOFF

FLT CONTROL..... CHECKED (BOTH)
 FLT INSTRUMENTS..... CHECKED (BOTH)
 BRIEFING..... CONFIRMED
 FLAPS SETTING..... CONF.(BOTH)
 V1, VR, V2 FLX TEMP.....CHECK (BOTH)
 TRANSPONDER (ATC)..... SET
 ECAM MEMO..... TO NO BLUE
 TAKEOFF RWY..... CONFIRMED (BOTH)
 CABIN..... ADVICE
 ENG MODE SEL..... AS RQRD
 TCAS..... TA / RA
 PACKS..... AS RQRD

AFTER TAKEOFF

LANDING GEAR..... UP
 FLAPS..... RETRACTED
 PACKS.....ON
 BARO REF..... STANDARD SET (BOTH)

APPROACH

BRIEFING..... CONFIRMED
 ECAM STATUS..... CHECKED
 SEAT BELTS..... ON
 BARO REF..... SET (BOTH)
 MIMIMUM..... SET (BOTH)
 ENG MOD SEL..... AS RQRD

LANDING

A / THR..... SPEED/OFF
 GO-AROUND ALT..... SET
 AUTOBRAKE..... AS RQRD
 ECAM MEMO..... LDG NO BLUE
 - L/G DOWN
 - SIGNS ON
 - CABIN READY
 - SPLRS ARM
 - FLAPS SET

PARKING

APU BLEED..... AS RQRD
 ENGINES..... OFF
 SEAT BELTS..... OFF
 EXTERNAL LIGHTS..... AS RQRD
 FUEL PUMPS.....OFF
 PARK BRK and CHOCKS..... AS RQRD
 MOBILE PHONE..... ON
 TRANSPONDER.....STBY 2000
 RADAR / PWS..... OFF
Consider HEAVY RAIN
 EXTRACT..... OVRD

SECURING THE AIRCRAFT

ADIRS..... OFF
 OXYGEN..... OFF
 APU BLEED..... OFF
 EMER EXIT LT..... OFF
 NO SMOKING..... OFF
 APU AND BAT..... OFF